

# FloodTape® User Instructions

## Installing FloodTape®:

1. Apply FloodTape® to dry dust free surface and use scissor or razor knife to cut
2. Allow min. 5" overlap at corners
3. Firmly press sticky side onto surface and mold into gaps and bumps
4. Only on corners peel off protective film and adhere FloodTape® together



## Removing FloodTape®:

1. Peel off protective film
2. Slowly pull tape backwards at a 45° angle

When removing the tape, it is important to pull back the tape SLOWLY towards you at a 45° or lower angle!

TIP: Removing the red protective film can be tricky. Grab only the sticky part (glue) on the corner of the FloodTape® and pull on it. The red protection film will separate itself from film and can then be easy grabbed and pulled off the tape.

## Recommended Tools:



45mm Silicone Seam Roller



Folding Utility Knife